


Vue éclatée HNS 5015 P



Partchart HNS 5015P

Item#	Part No.	Description	Q'ty
1	LH000060	Hex.Soc.Hd.Bolt	1
2	LH000061	Bushing	1
3	LH000062	Deflector	1
4	LH000063	Hex.Soc.Hd.Bolt	4
5	LH000064	Cap	1
6	LH000065	Cap Gasket	1
7	LH000066	Seal	1
8	LH000067	Piston Stopper	1
9	LH000068	O-Ring	1
10	LH000069	O-Ring	1
11	LH000070	Spring	1
12	LH000071	Piston,Head Valve	1
13	LH000072	O-Ring	2
14	LH000073	O-Ring	1
15	LH000074	O-Ring	1
16	LH000075	Cylinder Spacer	1
17	LH000076	O-Ring	1
18	LH000077	O-Ring	1
19A	LH000078	Driver Assembly	1set
20	LH000079	O-Ring	1
21	LH000080	Cylinder	1
22	LH000081	Bumper	1
23	LH000082	Driver Guide	1
24A	LH000083	Body Assembly	1set
25	LH000084	O-Ring	1
26	LH000085	End Cap	1
27	LH000086	O-Ring	1
28	LH000087	O-Ring	1
29	LH000088	Valve	1
30	LH000089	O-Ring	1
31	LH000090	O-Ring	1
32	LH000091	O-Ring	1
33	LH000092	Valve Plunger	1
34	LH000093	Spring	1
35	LH000094	O-Ring	2
36	LH000095	Plunger	1
37	LH000096	Plunger Cap	1
38A	LH000097	Trigger Assembly	1set
39	LH000032	Spring Pin	2
40	LH000099	Trigger Pin	2
41	LH000053	Grommet	2
42A	LH000101	Adjusting Button Assy.	1set
43	LH000102	Contact Trip Guide	1
44	LH000103	Adjusting Spring	1

Partchart HNS 5015P

Item#	Part No.	Description	Q'ty
45	LH000104	E-Ring	1
46	LH000105	Spring, Safety	1
47	LH000106	E-Ring	1
48	LH000107	Adjusting Nut	1
49	LH000108	Adjusting Post	1
50	LH000109	Adjusting Spring	1
51	LH000110	Steel Ball	2
52	LH000111	Upper Safety Lever	1
53	LH000112	Lower Safety Lever	1
54	LH000113	Hex.Soc.Hd.Bolt	2
55	LH000114	Spring Pin	1
56A	LH000115	Latch Spring Assembly	1set
57	LH000116	Spring Pin	1
58	LH000117	Lower Door	1
59	LH000118	Nose	1
60	LH000119	Nail Guide Liner	1
61	LH000120	Magazine	1
62	LH000121	Hex.Soc.Hd.Bolt	1
63	LH000122	Spring Stopper	2
64	LH000123	Hex.Soc.Hd.Bolt	2
65A	LH000124	Pusher Assembly	1set
66	LH000125	Spring Lock	2
67	LH000039	Spring	2
68	LH000127	Magazine Cover	1
69	LH000128	Spring Stopper	2
70	LH000129	Latch	1
71	LH000130	Spring Pin	2
72	LH000131	Spring	1
73	LH000132	Hex.Soc.Hd.Bolt	1
74	LH000133	Flat Washer	1
75	LH000134	Magazine Cap	1
76	LH000135	Locknut	3
77	LH000136	Magazine Cover Stopper	1
78	LH000137	Bracket	1
79	LH000138	Hex.Soc.Hd.Bolt	2
80	LH000139	Hex.Soc.Hd.Bolt	2
81	LH000140	Rubber Pad	1
82	LH000141	Clip	1
Special Kits			
D	LH000142	Dirver Maintenance Kit	1set
B	LH000143	Bumper Kit	1set
O	LH000144	O-Ring Maintenance Kit	1set