

Parts List

Item No.	Part No.	Description	Q'ty	Item No.	Part No.	Description	Q'ty
1	32206140766	Hex.Soc.Hd.Bolt	1	56	21592340001	Pin	2
2	20790000001	Bushing,Deflector	1	57A	21391521300	Safety Nose Assembly	1set
3	30106250866	Hex.Soc.Hd.Bolt	4	58	20971120001	Spring	1
4	20790010115	Deflector,Exhaust	1	59	20971180266	Feed Pawl	1
5	20750220001	Guide Cover	2	60	30700157000	O-Ring	6
6	207900202XX	Cap	1	61	20971170001	Roll Pin	2
7	20750130015	Gasket,Cap	1	62	20971140101	Feed Piston	1
8	20750140217	Piston Stopper	1	63	30700072000	O-Ring	1
9	20970160100	Spring	1	64	20971190012	Feed Spring	1
10	30700110000	O-Ring	1	65	20971090017	Feed Piston Bumper	1
11	30700111000	O-Ring	1	66	20971160101	Feed Piston Cover	1
12	20750150000	Piston,Head Valve	1	67	32522000001	C-ring	1
13	20750250117	Seal	1	68	20971270001	Shaft Pin Nail Guide	2
14	30700112000	O-Ring	1	69	20971300001	Spring	1
15	20790180116	Cylinder Seal	1	70	20971200001	Nail Stopper	1
16	20750370000	Cylinder Spacer	1	71	20971250266	Nail Guide	1
17	30700113000	O-Ring	1	72	30803120001	Spring Pin	1
18	30700121000	O-Ring	1	73	20971220001	Spring,Lock Shaft	1
19A	21590462001	Driver Assembly-Regular	1set	74	20971230266	Lock Shaft	1
20	30700075000	O-Ring	1	75	20971790015	Magazine Cover	1
21	20790350000	Cylinder	1	76	20011770015	Tension Post Bushing(Upper)	1
22	20750470115	Bumper	1	77	20011820101	Spring	1
23A	207506025XX	Body Assembly	1set	78	20971890015	Nail Holder	1
24	30700185000	O-Ring	1	79	20011810015	Adjust Post	1
25	207707X02XX	End Cap	1	80	20971840015	Magazine	1
26	30700079000	O-Ring	1	81	20971850001	Magazine Guide	1
27	30700081000	O-Ring	1	82	32704080166	Screw	3
28	20750900074	Valve	1	83	20011830015	Tension Post Bushing	1
29	30700071000	O-Ring	2	84	20971870001	Adjusting Nut	1
30	30700024000	O-Ring	1	85	30606100001	Locknut	2
31	30700002000	O-Ring	1	86	20971860001	Gauge Bracket	1
32	20750910074	Valve Plunger	1	87	30106300166	Hex.Soc.Hd.Bolt	2
33	20770960001	Spring	1	88	20971880001	Adjusting Plate	1
34	30700080000	O-Ring	2	89	30106120866	Hex.Soc.Hd.Bolt	1
35	20770920000	Plunger	1	90	30900003001	Flat Washer	2
36	20770930016	Plunger Cap	1	91	32806100001	Locknut	1
37A	20750952215	Trigger Assembly-Bump	1set	92	21501510101	Lower Safety Lever Assembly	1set
38	30803240001	Spring Pin	2	93	33304050166	Hex.Soc.Hd.Bolt	1
39	30700078000	Grommet	2	94	21593600066	Jaw A	1
40	20770890001	Pin Trigger	2	95	21593610066	Jaw B	1
41	20972840415	Guide, Contact Trip	1	96	21393620001	Spring	1
42	20771490001	Spring, Safety	1	97	30700136000	O-Ring	1
43	20971480001	Upper Safety Lever	1				
44	31303000001	E-ring	1				
45	20971600166	Adjusting Nut	1				
46	31200200000	Ball,Steel	2	Optional Parts			
47	20771630000	Adjusting Spring	1	98A	20970832215	Belt hook Assembly	1set
48	20971500001	Adjusting Post	1	98A-1	209707X01XX	End Cap	1
49	20011070000	Gasket	1	98A-2	20970830115	Belt hook	1
50	21591130066	Nose	1	98A-3	30700188000	O-Ring	1
51A	20973502100	Magnet Bushing Assembly	1set	98A-4	20970840001	Cover,Belt hook	1
52	21591540001	Guide,Safety Lever	1	98A-5	33425000001	C-Ring	1
53	30106220766	Hex.Soc.Hd.Bolt	5	99A	20770952359	Trigger Assembly-SEQ.	1
54	21501550015	Safety Cover	1	100A	21590572001	Driver Assembly-Shorter	1
55	20011760001	Bushing	2				

EXPLODED VIEW

