

**VUE ECLATEE**


**ET**

**LISTE DE PIECES**

**DE L'APPAREIL**

**HS 166 P**

# HS 166 P



# Partcharts HS 166P

Item No.	Part No.	Description	Q'ty
1	LH000230	Cap	1
2	LH000002	O-Ring	1
3	LH000003	O-Ring	1
4	LH000004	Cylinder Seal	1
5	LH000005	O-Ring	1
6	LH000006	O-Ring	1
7	LH000007	Cylinder	1
8	LH000008	O-Ring	1
9A	LH000238	Driver Assembly	1set
10	LH000010	Bumper	1
11	LH000240	Driver Guide	1
12	LH000012	O-Ring	1
13	LH000013	O-Ring	2
14	LH000014	Valve	1
15	LH000015	O-Ring	2
16	LH000016	Seal	1
17	LH000017	Valve Plunger	1
18	LH000018	O-Ring	1
19	LH000019	Spring	1
20	LH000020	O-Ring	2
21	LH000021	Plunger	1
22	LH000022	Plunger Cap	1
23A	LH000252	Body Assembly	1set
24	LH000024	Gasket	1
25	LH000025	End Cap	1
26	LH000026	Hex. Soc. Hd. Bolt	5
27	LH000256	Driver Guide Cover	1
28	LH000257	Door	1
29	LH000030	Hex. Soc. Hd. Bolt	2
30	LH000031	Trigger	1

# Partcharts HS 166P

Item No.	Part No.	Description	Q'ty
31	LH000052	Trigger Pin	1
32	LH000053	Grommet	1
33	LH000032	Spring Pin	2
34	LH000033	E-Ring	1
35	LH000034	Safety Lever	1
36	LH000035	Safety Spring	1
37	LH000036	Safety Pin	1
38	LH000267	Magazine Cover	1
39	LH000268	Pusher	1
40	LH000269	Spring	1
41A	LH000270	Magazine Assembly	1set
42	LH000271	Magazine Cap	1
43	LH000272	Spring Pin	2
44	LH000273	Spring Stopper	1
45	LH000274	Latch Spring	1
46	LH000275	Latch	1
47	LH000276	Pin	1
48	LH000277	O-Ring	1
49	LH000278	Hex.Soc.Hd.Bolt	1
50	LH000279	Washer	2
51	LH000138	Hex.Soc.Hd.Bolt	2
52	LH000050	Hex.Soc.Hd.Bolt	1
53	LH000135	Locknut	1
Special Kits			
D	LH000287	Dirver Maintenance Kit	1set
B	LH000284	Bumper Kit	1set
O	LH000285	O-Ring Maintenance Kit	1set